

ItemQtyDescription1438" S40 Vertical Extrusion2,2A2,212" Z45 Horizontal Extrusion3,3A1,125" Z45 Horizontal Extrusion

Steps

DESIGNS

- 1) Attach horizontals [2] and [2A] between verticals [1], with infills between.
- 2) Attach curved horizontals [3] and [3A] between front verticals [1], with infill between.
- 3) Place shelf on lip of extrusions [2]. See Extrusion Lip detail.
- 4) Set pedestal top on top of extrusions [2A] and [3].

© 2024







SETUP INSTRUCTIONS



Completed Pedestal Assembly



General Setup Instructions

- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing

- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.







Part Identification - Numbering





Spline Connection





Engaged Lock









MARNING

DO NOT USE POWER TOOLS

LADDERS OR LIFTS MAY BE REQUIRED

ALL CONNECTIONS MUST **BE TIGHTLY SECURED**



Top View of Each Level



