

#### Order #XXXXX MOD-1378 Sanitizer / iPad Stand

#### ★ iPad Holder Attachment

Attach connector piece to iPad holder. Then connect assembled iPad holder with connector to vertical extrusion.





Tighten set screw to secure A10 to Post. Tighten knob to secure graphic to A10 Clamp. Slide connector into groove of extrusion; secure with setscrew set screw screw cap  $\mathcal{P}$ Literature Pocket



www.classicexhibits.com



# **General Setup Instructions**

- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

# **Cleaning & Packing**

- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

## Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.



Hex Tool - Essential for Assembly





Part Identification - Numbering



Spline Connection

**Extrusion & Lock Connection** 



**Base Plate & Extrusion Connection** 



Engaged Lock







# MARNING

## DO NOT USE POWER TOOLS

#### LADDERS OR LIFTS MAY BE REQUIRED

### ALL CONNECTIONS MUST **BE TIGHTLY SECURED**