







Order #XXXXX General Information

General Setup Instructions

- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing

- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.
 Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials.
 All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.



Spline Connection

Hex Tool - Essential for Assembly





Part Identification - Numbering



Base Plate & Extrusion Connection



Extrusion & Lock Connection

Engaged Lock







WARNING

DO NOT USE POWER TOOLS

LADDERS OR LIFTS MAY BE REQUIRED

ALL CONNECTIONS MUST BE TIGHTLY SECURED



Order #XXXXX Counter Assembly



1) Mounting plate & wing nuts, in packed position.



2) Mounting plate bolt in, packed position.



3) Place mounting plate onto [10] then tighten bolt, part way, allowing some rotation for final positioning.



4) Place fixed counter bolts into mounting plate, then lift counter to re-tighten bolt.



5) Tighten bolt, using hex tool, to secure.



6) Place fixed counter bolts into mounting plate, then secure using wing nuts.

Keep mounting plate [11A] and wing nuts attached to counter, when packing.

Completed Assembly





Attach mounting plate to curved extrusion [10], using bolt. Insert fixed bolts, located on underside of counter, into holes of flange plate. Secure with wing nuts.

Keep bolt attached to [10], when packing.



Order #XXXXX Case Packing

SACAGAWEA^{© 2024}

DESIGNS



Order #XXXXX Backwall Assembly

SACAGAM





When Assembled

Keep extrusions [6A,6B] attached to [2B,3B].

Keep A10 clamps attached to [2A,2B,3A,3B].









Order #XXXXX LTK-1001 Counter Assembly

Setup Instructions:

SACAGAY

- 1) Attach pins at bottom interior of side panels. Note: Pins are designed to be slightly angled.
- 2) Use screw caps to secure the side panels to front panel and back panels, making sure Velcro is facing inward.
- 3) Slide floor into the bottom of assembled pedestal base. The floor will sit on pins of the side panels.
- 4) Connect shelf supports to Velcro on panels, then place shelf on top of supports.

© 2024

DESIGNS

5) Attach pedestal top to assembled pedestal base. See Pedestal Top Attachment detail.









Completed Pedestal Assembly

